



Trusting - 6006 - Kit de freno premontado

- Ford
- Trasero
- Bendix/Bosch
- Ø Tambor [mm]: 180
- Ancho Zapata [mm]: 30
- Ø Bombín [mm]: 17,46