



Trusting - 6091 - Kit de freno premontado

- Renault
- Trasero
- Bendix/Bosch
- Ø Tambor [mm]: 180
- Ancho Zapata [mm]: 42
- Ø Bombín [mm]: 20,64