



Trusting - 6185 - Kit de freno premontado

- Smart
- Trasero
- Bendix/Bosch
- Ø Tambor [mm]: 200
- Ancho Zapata [mm]: 32
- Ø Bombín [mm]: 22,20