



Trusting - 6191 - Kit de freno premontado

- VW
- Trasero
- VAG
- Ø Tambor [mm]: 200
- Ancho Zapata [mm]: 40
- Ø Bombín [mm]: 20,64