



Trusting - 6196 - Kit de freno premontado

- VW
- Trasero
- VAG
- Ø Tambor [mm]: 230
- Ancho Zapata [mm]: 40
- Ø Bombín [mm]: 22,20