



Trusting - 6202 - Kit de freno premontado

- Opel / Renault
- Trasero
- VAG
- Ø Tambor [mm]: 254
- Ancho Zapata [mm]: 57
- Ø Bombín [mm]: 25,40