



Trusting - 6242 - Kit de freno premontado

- Opel
- Trasero
- TRW
- Ø Tambor [mm]: 230
- Ancho Zapata [mm]: 50
- Ø Bombín [mm]: 17,46