



## Trusting - 6311 - Kit de freno premontado

- Ford
- Trasero
- TRW
- Ø Tambor [mm]: 203
- Ancho Zapata [mm]: 38
- Ø Bombín [mm]: 20,64