



Trusting - 6382 - Kit de freno premontado

- Opel
- Trasero
- Lockheed
- Ø Tambor [mm]: 203
- Ancho Zapata [mm]: 38
- Ø Bombín [mm]: 19,05